


Biodegradable  
polymer scaffold



*In vitro* tissue culture



*In vivo* implantation



**New**

Bone  
Cartilage  
Liver  
Intestine  
Ureter

## Cells

Osteoblasts  
Chondrocytes  
Hepatocytes  
Enterocytes  
Urothelial cells





20KV 121X 100U 1873 V-HEPTA



# Cartilage tissue engineering

---



BEFORE  
cell seeding



AFTER  
2 weeks in culture







# System

---

- Modified poly glycolic acid (PGA) tubes
- 8 weeks SMC culture, then EC
- Bio-Reactors – Pulsatile radial stress








# Characteristics

---

- 50% collagen
- Rupture strengths > 2000 mg Hg
- Suture retention – Strengths up to 90g
- Demonstrates contractile responses to serotonin, endothelin-1, and prostaglandin F2 $\alpha$














**a) Glycosoaminoglycan**  
(X 40, safranin-O)




**b) Collagen**  
(X 400, trichrome, fluorescent light)





**c) Glycosoaminoglycan**  
(X 400, safranin-O)



**d) Chondroitin Sulfate**  
(X 400, alcian blue)






























# Cell encapsulation: Can cells be protected with materials?





Can a device be made to allow transplanted cells to live and function, but protect them from the immune system? What material will we use?

Only a few materials have been investigated  
– most work has been with alginate from seaweed




# Islet encapsulation in alginate microbeads



electrostatic droplet  
generator






# Transplanted, encapsulated islets become covered in scar tissue




- Alginate is not sufficiently biocompatible and is recognized as a foreign material
- Can we develop materials that keep cells alive and functioning but do not get covered in scar tissue?



# Automated, high throughput polymer synthesis





Current progress for the alginate modification library. Numbers indicate the number of unique, diverse alginates that correspond to each general structure.

# Rapid evaluation of biocompatibility


---

- How do we rapidly evaluate whether a material is superbiocompatible?
- Conventional biocompatibility analysis is slow and requires tissue histology.
- Can we evaluate the inflammation response rapidly?




# Improved biocompatibility *in vivo*

263\_C12



Unmodified Alginate



The modified alginate is covered with a thin fibrotic layer (blue, pointed with arrow) surrounding all of the capsules and with very little collagen infiltrating and surrounding individual particles. The fibrotic layer is approximately 1-2 layers thick which indicates a score of 1. Unmodified alginate has collagen penetrating the fibrotic capsule (arrow) along with a large amount of collagen clustering on the sides of the implant. The concentric fibrotic coverage indicates a score of 3 for unmodified alginate.

---

**Can other  
technologies help  
tissue engineering?**

# Slow release of active factors from polymer

---

## Growth Factors


- Basic FGF
- EGF
- NGF

## Growth Inhibitors

## Differentiating Factors


- The Retinoids


## Anti-Inflammation Agents













# Microencapsulated islets release scar-blocking over an extended time after implantation

---

No drug in capsule



Drug releasing capsules after implantation



Drug releasing capsules capable of treating diabetic mice

# The gene therapy bottleneck: Delivery

---

“There are only three problems in gene therapy: delivery, delivery, and delivery.”

—Inder Verma, 1999

## Primary Concerns:

- Safety
- Efficiency

## Viral Vectors

- Highly efficient
- Safety concerns

## Synthetic Vectors

- Potentially safer
- Cheaper and easier to manufacture
- Currently less efficient



# Goal:

Using simple robotic systems, develop high-throughput synthesis and screening methods

## Synthesis:



94 Amino monomers

X

25 diacrylate monomers


=

2350 Structurally diverse, degradable polymers




# Human embryonic stem cells

---




**C32-118**




**Lipofectamine 2000**

---

**Can new  
materials help?**








# Cyclic elongation of biorubber

---



15 x 5 x 0.7 mm    500mm/min    100% strain    5 cycles

# Mechanical properties - Elongation



E = 0.282 to 2.75 MPa

Dimension: 25x5x0.7 mm

Deflection rate: 50 mm/min

---


**Can polymer architecture  
help?**





Degradable suture material  
tied to hold both parts of the  
implant together

Oriented portion of the  
implant providing axonal  
guidance

Inner portion of the  
implant with large  
pores seeded with  
neural stem cells





# Materials can affect cell behavior

---

Soluble factors: Media, growth factors




Insoluble factors: ?

Can we identify polymers that can control cell behavior?



# The solution: Microarrayed polymers

---






























# Design challenges for polymer microarrays:



---

- Synthesize large numbers of diverse materials in nanoliter volumes
- Attach materials to slide in a manner compatible with diverse materials and an aqueous environment
- Cell growth must be limited to polymer spots to be independent of neighbor effects
- Designed to allow simple, simultaneous assay of cellular markers

# Chemical diversity through acrylate polymerization



# Design of a cell compatible microarray




A vertical diagram showing a grid of small green dots representing polymer spots. Three pairs of squares, one red and one yellow, are overlaid on the grid to indicate specific regions of interest.

25 different monomers mixed pairwise at 70:30 v/v ratios


576 polymer spots in triplicate:  
1728 individual polymer spots

# Cell compatible polymer micro arrays





Print 1500-3500 individual polymer composites on a single slide in a cell compatible format

Cells can only grow on the polymers NOT in the spaces between them






# Tens of thousands of experiments can be performed simultaneously



20 slides with 1500-3500 individual spots can be synthesized in a single day



+

media, growth factors, etc.

+

different time periods

All 20 slides (or more) can be seeded with cells and examined with different media, cells or at different time points




# Example

---

Can we convert human embryonic stem cells to epithelial cells?

# Rapid synthesis and characterization of cell-polymer interactions




Green: Cytokeratin

Red/purple: Vimentin

Blue: Polymer

# Rapid characterization of growth support





# Multiple experiments in multiple conditions

Monomer Composition	RA Day 6		Day 6 24hr RA Pulse		Day 6 No RA		RA Day 1		Day 1 No RA	
100% <b>1</b>										
70% <b>1</b> , 30% <b>*</b>										
100% <b>3</b>										
70% <b>3</b> , 30% <b>1</b>										
70% <b>3</b> , 30% <b>18</b>										
70% <b>3</b> , 30% <b>21</b>										
100% <b>6</b>										
100% <b>13</b>										
100% <b>7</b>										
70% <b>7</b> , 30% <b>4</b>										
70% <b>7</b> , 30% <b>*</b>										
100% <b>11</b>										
70% <b>11</b> , 30% <b>1</b>										
70% <b>11</b> , 30% <b>21</b>										
100% <b>12</b>										
70% <b>12</b> , 30% <b>3</b>										
70% <b>12</b> , 30% <b>21</b>										
100% <b>18</b>										
70% <b>18</b> , 30% <b>*</b>										
70% <b>18</b> , 30% <b>13</b>										
100% <b>21</b>										
100% <b>23</b>										
70% <b>23</b> , 30% <b>1</b>										
70% <b>23</b> , 30% <b>21</b>										


Polymers that support/inhibit  
growth of hES cells

Polymers that support growth  
only in certain media

Polymers that support growth  
of certain cell types

# The present state-of-the-art: hPSCs cultured on MEFs

---



Mouse embryo  
fibroblasts (MEFs)

hPSCs

hPSCs are currently passaged as small clumps of cells.  
It can be challenging to genetically engineer hPSCs.



# Maintenance on mouse embryo fibroblast feeder layers

---























- Production of MEF is laborious and this limits large scale production of hESC's
- Animal pathogen and animal immunologic protein contamination

# Feeder free substrates; (ECM)/serum proteins


---

- Don't support efficient growth (i.e., less than 10%) of hESC's from fully dissociated cells
- Don't support long term growth
- Don't support clonal growth of single human cells

**a**



# Polymerization scheme



Copolymerization between acrylate monomers enables us to rapidly construct polymer libraries with diversified properties.

# Hits

---

- Screened for SSEA4 and OCT4
- Monomer 9, copolymer with monomer A shows comparable efficiency to MEF
- Does not correlate with surface roughness (AFM), hydrophobicity, elastic modulus



# Hits (cont.)

---

- Correlates with surface structures with hydrocarbon ions ( $C_2H_3^+$ ,  $C_3H_3^+$ ), oxygen containing ions from esters ( $CHO_2^-$ ,  $C_3H_3O^+$ ,  $C_2H_3O^+$ ) and ions from cyclic structures ( $C_6H^-$ ,  $C_4H^-$ ,  $C_2H^-$ )
- After 10 passages – full pluripotent potential as judged by multiple hESC markers (Tral-60, Nanog, Oct4, Sox2, SSEA4) karyotype, and gene expression (into all 3 germ lineages)
- Ultimate system is chemically defined, xeno-free, feeder free